

TAIL LIGHT Installation manual

- Step 1: Put all the bulbs into the bulb holder socket.
Two bulbs come with the tail light from Sonar:
1. Clear bulb 5W for position light
2. Amber bulb 21W for Indicator light
For the rest of the bulbs, please use the original ones.
- Step 2: Fit the bulb holder (wiring kits) to the tail light socket holes.
- Step 3: Fix the Impedance (Electric Resistance) to "position 4" of the car body in the following picture before installation.
- Step 4: Slightly move the tail light upward until the screw fall into the screw hole in "position 2". Screw it but do not tighten it up completely or over tighten before step 6 is done.
- Step 5: Insert the screw ball into "position 1" (push from the lens)
- Step 6: Insert the screw into the screw hole in "position 3". Ensure that the screws in "position 3" is correctly in place and then tighten up both screws in "position 2" & "position 3".
- Step 7: Plug the female connector in the male connector (from car) to finish the installation.

Thank you for buying SONAR products.

